

MS864-8 电子锁 ELECTRONIC LOCK

NEW



材质及表面处理: 锌合金基座、手柄, 黑色喷塑, 不锈钢钢柱
备注: 电子锁与机械锁默认钥匙都为K04-3

Material and surface finish: ZDC housing, handle, black powder coated, stainless steel cam.

Remark: default key K04-3 for both of electronic lock and mechanical lock.

该锁为把手旋转角度90度, 单向锁定行程25mm的三点锁住锁。

在锁体结构不变的情况下, 可以通过调换定位件方向来调节左右开门。

更换电子盒组件来实现电子锁与机械锁的互换。

电子锁在通电的情况下, 指示灯开始闪烁绿色灯光, 手柄没有打开(此时如断开电源, 该锁将自动关闭)。按手柄圆圈位置手柄自动弹起, 完成开启功能。

30秒电源断开(时间由客户设置建议设置时间不超过1分钟)。此时按下手柄, 完成关闭功能。如出现意外(比如: 远程控制失效, 电源线烧毁等)无法使电子锁通电的情况下。可参照以下机械锁开启方式。

机械锁开启方法: 用专用工具钥匙旋转五角螺钉, 打开防尘盖。再使用钥匙开启锁芯。手柄自动弹起完成开启功能。

电子盒的使用要求: 输入额定电压12V~24V/DC, 额定电流200mA~300mA/DC。红线--正极, 蓝色--负极, 绿色黄色--信号线。

Without changing the structure, you can open door either in left open, or right open by changing Fix parts. Change the part of electronic box, locks can be exchanged between electronic lock and mecanism lock.

The green signal starts to shine when electricity is switched on, the handle is not open (if cut off the power, the lock can be locked automatically). When press on the circular sign, the swing handle will release from its recession. The electricity circuit will be kept on for 30 seconds (This time can be set by customers, it's recommended the time doesn't excess 1 min), while press the swing handle, the power is cut off. If false locking occurs (when electricity is mistakenly switched on), please refer to the method of unlocking mecanism lock.

The method of unlocking mecanism lock: use five-angle screws with a special tool, open proof-dust cover, then use key to open, the swing handle will release.

Electronic box usage requirement: Input volty 12V-24V, rating currence 200mA-300mA/DC

Redline: positive Blue line: negative Green and yellow: signal line



关闭状态

机械开锁

通电开启

安装方式

安装要求

门锁在门上的安装过程中, 不得敲击门锁, 以免损坏门锁零件, 操作人员需戴手套。
安装时门板需保持水平。柜门固定孔须与锁体外形相对。不可用重力敲打锁体。不可用化学物质擦拭锁体表面以防电镀层腐蚀。
安装后锁体保持平面度和垂直度。门锁与门板安装接口处无须涂防水胶就能够达到IPX6的防水等级。

Installation requirement

While installate, don't hammer the lock, or easy to damage lock accessories, operator should wear gloves. Make sure the door is horizontal. The fix hole matches the shape of lock. Don't hammer lock, and don't clear the surface of locks to avoid errision the plate layer.
After installion the body should be in horizontal with door. The gaps between the lock and the hole should be filled with gel to reach IPX6protect rate.